

WIRING DIAGRAMS

TABLE OF CONTENTS

Paragraph Number	Title	Effectivity	Page Number
98-1	Wiring Diagrams.....	TH-57B / C	98-02

LIST OF FIGURES

Figure Number	Title	Effectivity	Page Number
98-1	KLN 900 GPS W/Autopilot Wiring Diagram.....	TH-57C	98-03
98-2	Audio/ICS Wiring Diagram.....	TH-57B / C	98-13
98-3	COMM 1System Wiring Diagram.....	TH-57B	98-15
98-4	COMM 2 System Wiring Diagram.....	TH-57C	98-16
98-5	Air Conditioning Electrical Installation Wiring Diagram	TH-57B / C	98-17
98-6	Air Conditioning Electrical System Wiring Diagram.....	TH-57B / C	98-22
98-7	Navigation and Navigational Aids Systems Wiring Diagrams.	TH-57B / C	98-23
98-8	Marker Beacon System Wiring Diagram.....	TH-57B / C	98-25
98-9	Radar Altimeter System Wiring Diagram.....	TH-57B / C	98-26
98-10	Flight control/MINISTAB systems wiring diagram.....	TH-57C	98-27
98-11	C6533/ARC Intercommunication System.....	TH-57B	98-28
98-12	Electrical Power System Wiring Diagram.....	TH-57C	98-32
98-13	Lighting Circuits Wiring Diagram.....	TH-57C	98-36
98-14	Environmental Control System Wiring Diagram.....	TH-57B / C	98-38
98-15	KT-79 Interconnect Diagram.....	TH-57B	98-39
98-16	UHF Wiring Diagram	TH-57C	98-40
98-17	Auto Fault Chip Detector Wiring Diagram	TH-57B / C	98-41
98-18	KX-155 Com-Nav Wiring Diagram.....	TH-57B	98-43
98-19	KRA-405 Radar Altimeter Wiring Diagram.....	TH-57B	98-44
98-20	Heading System / Navigation System Wiring Diagram	TH-57B	98-45
98-21	Electrical System	TH-57B	98-46
98-22	Electrical System	TH-57C	98-47

WIRING DIAGRAMS

98-1. WIRING DIAGRAMS.

This section contains diagrams of instrument, electrical, and flight control/MINISTAB systems of the TH-57B and C helicopter. Wiring diagrams are provided to assist in understanding

system logic and interaction of components and systems, and to aid in troubleshooting malfunctioning systems. Contents and layout of diagrams correspond to troubleshooting charts and appropriate text.